Here are the basic troubleshooting steps. If you are still experiencing issues, please contact Customer Support. for further assistance.

TROUBLESHOOTING

- Step 1: Take the batteries out of the device and pull the prongs towards the center of the device.
- Step 2: Clean the battery contacts with rubbing alcohol by using a Q-Tip.
- Step 3: Clean the conductor head contacts on the conductor and on the device with rubbing alcohol
- Step 4: Replace the batteries with new ones.