

PRE-TREAT PHASE

step 1: Evenly apply an entire ampoule of pre-treat gel to the entire face and neck, avoiding eyes, eyelids, and lips.

step 2: Push the selection button until the number 1 is lit on the display. This treatment will take 2 minutes.

step 3: Thoroughly wet hands with NaPCA Moisture Mist or water. Hold the device with a moistened hand while touching the chrome plate on the back and begin to slowly glide the conductor head over your skin. Be sure to avoid sensitive areas like your eyes, eyelids, and lips.

The device will beep once, twice, or three times to indicate that it has automatically adjusted to your skin. After this, your galvanic treatment has begun, and the device will beep every 10 seconds to indicate the unit is on and working, and every 5 seconds when your treatment is almost complete

step 4: When your galvanic treatment is over, the device will emit a long beep followed by two short beeps and automatically turn off. Remove any remaining gel from your skin and the device with a damp towel.. Now it's time for the treatment phase.

TREATMENT PHASE

step 1: Apply an entire ampoule of treatment gel to your face and neck.

step 2: The ageLOC® Face Conductor should already be attached, so press the selection button once to turn the device back on and keep pressing until you select treatment number 2. This treatment will take 3 minutes.

step 3: Again, hold the device with a moistened hand while touching the chrome plate on the back, and begin to slowly glide the conductor head over your skin. Be sure to avoid sensitive areas like your eyes, eyelids, and lips.

The device will beep one, two, or three times to indicate that it has automatically adjusted to your skin. After this, your galvanic treatment has begun, and the device will beep every 10 seconds to indicate the unit is on and working, and every 5 seconds when your treatment is almost complete.

step 4: When your galvanic treatment is over, the device will emit a long beep followed by two short beeps and automatically turn off. Use a damp towel to remove any remaining gel from your skin and the device.
